



# DC Bridges-II


---

KELVIN DOUBLE BRIDGE AND  
BRIDGES WITH STRAIN GAUGE  
AND TEMPERATURE SENSORS

# DC BRIDGES – KELVIN DOUBLE BRIDGE

---

- ❑ It is used to solve the problem of connecting leads.
- ❑ It has two balanced ratio and can measure small resistance ( $0.0001\Omega$ ) with error 0.1%
- ❑ Kelvin bridge is a modified version of the Wheatstone bridge.
- ❑ The purpose of the modification is to eliminate the effects of contact, and lead resistance when measuring unknown low resistances.
- ❑ Resistors in the range of approximately 1 microohm to 1 ohm may be measured with a high degree of accuracy using a bridge called the *Kelvin bridge*



# Contd..

---

The resistance  $R_y$  is the resistance from  $R_3$  to  $R_x$ .

Where  $R_x$  is Unknown resistance

$$R_{cb}/R_{ab} = R_1/R_2 \quad (1)$$


Bridge in Balance form is

$$R_2 R_x = R_1 R_3 \quad (2)$$

$R_3$  is changed to  $R_3 + R_{ab}$  and  $R_x$  is changed to  $R_x + R_{cb}$

Modify equation (2) as

$$R_2(R_x + R_{cb}) = R_1(R_3 + R_{ab}) \quad (3)$$



Contd..

---

$$(R_x + R_{cb}) = \frac{R_1}{R_2} (R_3 + R_{ab}) \quad (4)$$

$$\frac{R_{cb} + R_{ab}}{R_{ab}} = \frac{R_1 + R_2}{R_2}$$

but  $R_{cb} + R_{ab} = R_y$

Now

$$\frac{\mathbf{R}_{cb}}{\mathbf{R}_{ab}} = \frac{\mathbf{R}_1}{\mathbf{R}_2}$$

$$\frac{R_y}{R_{ab}} = \frac{R_1 + R_2}{R_2}$$

$$\frac{R_{cb}}{R_{ab}} + 1 = \frac{R_1}{R_2} + 1$$

$$R_{ab} = \frac{\mathbf{R}_2 R_y}{\mathbf{R}_1 + \mathbf{R}_2}$$

Contd..

---

Similarly

$$R_{cb} = \frac{R_1 R_y}{R_1 + R_2}$$

$$(R_x + R_{cb}) = \frac{R_1}{R_2} (R_3 + R_{ab}) \quad (4)$$

Substitute value of  $R_{cb}$  and  $R_{ab}$  in eq (4)

$$R_x + \frac{R_1 R_y}{R_1 + R_2} = \frac{R_1}{R_2} \left( R_3 + \frac{R_2 R_y}{R_1 + R_2} \right)$$

$$R_x = \frac{R_1 R_3}{R_2}$$

# BRIDGE AMPLIFIER WITH STRAIN GAUGE



---

Gauge factor,  $G_F$

$$G_F = \frac{\Delta R/R_0}{\Delta L/L} = \frac{\Delta R/R_0}{\varepsilon}$$

$$R_3 = R_0 + \Delta R = R_0 (1 + \Delta R/R_0)$$

$$R_3 = R_0 (1 + G_F \varepsilon)$$



# Measurement of strain


---

$$V_0 = V_{dc} \left[ \frac{R_2}{R_1 + R_2} - \frac{R_4}{R_3 + R_4} \right]$$

but  $R_3 = R_0(1+G_F\varepsilon)$

$$V_0 = V_{dc} \left[ \frac{R_2}{R_1 + R_2} - \frac{R_4}{R_0(1+G_F\varepsilon) + R_4} \right]$$


$$\varepsilon = \frac{R_4}{G_F R_0} \left[ \frac{1}{\left( \frac{R_2}{R_1 + R_2} - \frac{V_0}{V_{dc}} \right)} - 1 \right] - \frac{1}{G_F}$$



# BASIC BRIDGE AMPLIFIER

---

- ❑ A Basic bridge amplifier is consist of an Op Amp, four resistors and transducer.
- ❑ The transducer is device that converts non electrical quantity to electrical one or vice versa.
- ❑ A strain gauge is also a transducer whose resistance change with the strain.
- ❑ Photoconductive cells are light-sensitive resistors in which resistance decreases with an increase in light intensity when illuminated is another type of transducer.



# CIRCUIT ANALYSIS

---

The resistance of transducer is represented by

$$R_{transducer} = R_{ref} + \Delta R \quad (1)$$


$\Delta R$ =amount of change in R.

A thermistor has resistance of  $10,000\Omega$  at temperature of  $25^\circ\text{C}$ .

A temperature change of  $26^\circ\text{C}$  results in resistance of  $9573\Omega$ .

So using equation (1)


$$\Delta R = -427\Omega$$



# Contd..

---

- This Bridge amplifier requires a stable dc or ac supply E.
- The power supply should have small internal resistance than R.
- So a specific circuit is used for generating of the stable power supply in which voltage divider circuit is used together with op amp.
- The OP amp act as voltage follower and E can be adjusted between +10 and -10 V.



# Temperature measurement with Thermistor

---

Step1 Select any thermistor such as 701033 or UUA41J1

Step2 Connect this to one arm of the bridge amplifier.

Step 3 Select the reference temperature. e.g. 20 degree C

Step 4 At reference temperature the voltage should be zero and calculate the resistance at this value.

Step 4 Predict the voltage temperature characteristics and calculate the I and V for each



# Sensitivity of Wheatstone Bridge

Let for unbalance  $R$  is changed to  $R + \Delta R$

$$e = E_{AD} - E_{AB} = I_2 (R + \Delta R) - I_1 P$$


$$= \frac{E}{R + \Delta R + S} (R + \Delta R) - \frac{E}{P + Q} P$$

$$= E \left[ \frac{R + \Delta R}{R + \Delta R + S} - \frac{P}{P + Q} \right]$$

$$\text{As } \frac{P}{Q} = \frac{R}{S} \quad \text{or } \frac{P}{P+Q} = \frac{R}{R+S}$$

$$= E \left[ \frac{R + \Delta R}{R + \Delta R + S} - \frac{R}{R+S} \right] = \frac{ER}{R+S} \left[ \left( \frac{1 + \frac{\Delta R}{R}}{1 + \frac{\Delta R}{R+S}} - 1 \right) \right]$$

$$= \frac{ER}{R+S} \left[ \left( 1 + \frac{\Delta R}{R} \right) \left( 1 - \frac{\Delta R}{R+S} + \frac{(ER)^2}{(R+S)^2} + \dots \right) - 1 \right]$$



Contd..

$$= \frac{ESR}{(R+S)^2}$$

Let  $S_V$  be voltage sensitivity of galvanometer

Galvanometer Deflection  $\Theta = S_V e = S_V \frac{ESR}{(R+S)^2}$

Let  $S_B$  is bridge sensitivity  $\rightarrow$  It is deflection of galvanometer per unit fractional change in unknown resistance

$$S_B = \frac{\Theta}{\frac{\Delta R}{R}} = \frac{S_V ESR}{(R+S)^2}$$

Contd..

$$S_B = \frac{S_V E}{\left(\frac{(R+S)}{RS}\right)^2} = \frac{S_V E}{\left(\frac{R+2+\frac{S}{R}}{S}\right)} = \frac{S_V E}{\frac{P}{Q} + 2 + \frac{Q}{P}}$$

For bridge with curvy arm resistance

$$R=S=P=Q$$


$$S_B = \frac{S_V E}{1+2+1} = \frac{S_V E}{4}$$

$$R_{th} = \frac{RS}{R+S} + \frac{PQ}{P+Q}$$

$$\text{If } P=Q=R=S$$

$$R_{th} = \frac{R \cdot R}{R+R} + \frac{R \cdot R}{R+R} = \frac{R^2}{2R} + \frac{R^2}{2R} = \frac{2R(R)}{2R} = R$$

$$E_{th} = E \left[ \frac{R+\Delta R}{R+\Delta R+S} - \frac{P}{P+Q} \right] = E \left[ \frac{\frac{R+\Delta R}{2R+\Delta R} - \frac{1}{2}}{\frac{Q}{2R+\Delta R}} \right]$$



Contd..


$$I_g = \frac{E_{th}}{R_{th} + R_g}$$

$$= \frac{E \Delta R}{4R}$$

$$\frac{R_{th} + R_g}{R_{th} + R_g}$$

$$\textcircled{O} = \frac{S_v ESR}{(R+S)^2}$$

deflection



$$S_v = \frac{S_i}{R_{th} + R_g} \rightarrow$$

current sensitivity of galvanometer

$$\textcircled{O} = \frac{S_i ESR}{(R+S)^2 (R_{th} + R_g)}$$

For P = Q = R = S

$$\textcircled{O} = \frac{S_i E \Delta R}{4R(R_{th} + R_g)} \quad S_B = \frac{S_i E}{4(R_{th} + R_g)}$$

# References

---

[Kalsi H S, Electronic instrumentation](#), Tata McGraw-Hill Education, 2004

[E.O. Doebelin, Measurement System](#), Tata McGraw-Hill Education, 2013.

A.K Sawhney,, Electrical and Electronics Measurements.