



Binary Eutectic Phase Diagram

Thapar Institute of Engineering & Technology
(Deemed to be University)

Bhadson Road, Patiala, Punjab, Pin-147004

Contact No. : +91-175-2393201





Email : info@thapar.edu



THAPAR INSTITUTE
OF ENGINEERING & TECHNOLOGY
(Deemed to be University)

Three Phase Reactions


2

Eutectic	Cooling \longrightarrow $L \rightarrow \alpha + \beta$ \longleftarrow heating	 A schematic phase diagram for a eutectic reaction. It shows a horizontal eutectic isotherm. To the left of the isotherm, a single phase α is shown. To the right, a single phase β is shown. Above the isotherm, a single phase L (liquid) is shown. Below the isotherm, the two-phase region is labeled $\alpha + \beta$. The isotherm itself is a horizontal line connecting the α and β phase regions, with L above it and $\alpha + \beta$ below it.
Peritectic	Cooling \longrightarrow $\alpha + L \rightarrow \beta$ \longleftarrow heating	 A schematic phase diagram for a peritectic reaction. It shows a horizontal peritectic isotherm. To the left, a single phase α is shown. To the right, a single phase L (liquid) is shown. Above the isotherm, the two-phase region is labeled $\alpha + L$. Below the isotherm, a single phase β is shown. The isotherm connects the α and L phase regions, with $\alpha + L$ above it and β below it.
Eutectoid	Cooling \longrightarrow $\gamma \rightarrow \alpha + \beta$ \longleftarrow heating	 A schematic phase diagram for a eutectoid reaction. It shows a horizontal eutectoid isotherm. To the left, a single phase α is shown. To the right, a single phase β is shown. Above the isotherm, a single phase γ is shown. Below the isotherm, the two-phase region is labeled $\alpha + \beta$. The isotherm connects the α and β phase regions, with γ above it and $\alpha + \beta$ below it.
Peritectoid	Cooling \longrightarrow $\alpha + \beta \rightarrow \gamma$ \longleftarrow heating	 A schematic phase diagram for a peritectoid reaction. It shows a horizontal peritectoid isotherm. To the left, a single phase α is shown. To the right, a single phase β is shown. Above the isotherm, the two-phase region is labeled $\alpha + \beta$. Below the isotherm, a single phase γ is shown. The isotherm connects the α and β phase regions, with $\alpha + \beta$ above it and γ below it.

Binary Eutectic Systems (easily melted)

3

When solid solubility is limited and the melting points of the components are not vastly different. **Pb-Sn Equilibrium Phase Diagram**



Binary Eutectic Phase Diagram



4

Gibbs Phase Rule

$$F = C - P + 1$$

Pressure: 1 atm.

Eutectic Reaction:



EX 1: Pb-Sn Eutectic System

5

- For a 40 wt% Sn-60 wt% Pb alloy at 150°C, determine:
 - the phases present

Answer: $\alpha + \beta$

-- the phase compositions

Answer: $C_\alpha = 11$ wt% Sn


$C_\beta = 99$ wt% Sn

-- the relative amount of each phase

Answer:

$$W_\alpha = \frac{S}{R+S} = \frac{C_\beta - C_0}{C_\beta - C_\alpha}$$
$$= \frac{99 - 40}{99 - 11} = \frac{59}{88} = 0.67$$

$$W_\beta = \frac{R}{R+S} = \frac{C_0 - C_\alpha}{C_\beta - C_\alpha}$$
$$= \frac{40 - 11}{99 - 11} = \frac{29}{88} = 0.33$$



EX 2: Pb-Sn Eutectic System

- For a 40 wt% Sn-60 wt% Pb alloy at 220°C, determine:
 - the phases present:

Answer: $\alpha + L$

- the phase compositions


Answer: $C_\alpha = 17 \text{ wt\% Sn}$
 $C_L = 46 \text{ wt\% Sn}$

- the relative amount of each phase

Answer:


$$W_\alpha = \frac{C_L - C_0}{C_L - C_\alpha} = \frac{46 - 40}{46 - 17}$$
$$= \frac{6}{29} = 0.21$$

$$W_L = \frac{C_0 - C_\alpha}{C_L - C_\alpha} = \frac{23}{29} = 0.79$$








□ For alloys where $C_o < 2 \text{ wt\% Sn}$

□ Result at room temperature is a polycrystalline with grains of a phase having composition C_o .



□ $2 \text{ wt\% Sn} < C_o < 18.3 \text{ wt\% Sn}$

□ Results in polycrystalline microstructure with α grains and small β -phase particles at lower temperatures.





Microstructure development


9

□ $C_o = C_E$

□ Results in a eutectic microstructure with alternating layers of α and β crystals.



- A **2-phase microstructure** resulting from the solidification of a liquid having the **eutectic composition** where the phases exist as a lamellae that alternate with one another.
- Formation of eutectic layered microstructure in the Pb-Sn system during solidification at the eutectic composition. Compositions of α and β phases are very different. Solidification involves redistribution of Pb and Sn atoms by **atomic diffusion**.





Microstructure development

11


□ $C_o = 30 \text{ wt. \% Sn}$

□ Microstructure consists of primary α phase and an eutectic structure between α and β phases



Hypoeutectic & Hypereutectic

12




12

Iron-Carbon Phase Diagram

13

Identify the different reactions in this phase diagram



1. Binary eutectic phase diagram have a composition where it behaves like a metal called as eutectic composition.
2. Lamellar structure forms at the eutectic composition and below eutectic temperature.
3. Below and above the eutectic composition, the microstructure has primary or proeutectic alpha or beta phase also.